

Videoflex Vinyl - Matt Finish

Iron On Instructions

Temperature: 160°C to 180°C

Time: 10 Seconds

Pressure: Very Firm

Remove Clear Film when cool.

Reflective Silver Videoflex

Iron On Instructions

Temperature: 150°C to 160°C

Time: 10-15 Seconds

Pressure: Very Firm

Remove Clear Film when cool.

Videoflex P.S. - Sticky Back

Iron On Instructions

Temperature: 150°C to 160°C

Time: 10 - 15 Seconds

Pressure: Medium

Remove Clear Film while still HOT!!

Stretch P.S. - Sticky Back

Iron On Instructions

Temperature: 150°C to 160°C

Time: 10 - 15 Seconds

Pressure: Medium - Firm

Remove Clear Film while Warm.

Videoflex Fluro Finish

Iron On Instructions

Temperature: 150°C to 160°C

Time: 10 Seconds

Pressure: Very Firm

Remove Clear Film when cool.

Video Flock - Felt Finish

Iron On Instructions

Temperature: 170°C to 180°C

Time: 10 Seconds

Pressure: Very Firm

Remove Clear Film when cool.

3D XPD - Puff Finish

Iron On Instructions

Temperature: 170°C to 180°C

Time: 3sec then 20sec to RAISE.

Pressure: 3 sec at Medium. Then Hold plate above material for 20 to raise puff.

Sublistop

Iron On Instructions

Temperature: 165°C to 170°C

Time: 15seconds

Pressure: Very Firm

Remove Clear Film when cool.

Poli-Flex Blockout - Sticky Back

Iron On Instructions

Temperature: 155°C to 165°C

Time: 17 - 20 seconds

Pressure: Medium

Remove Clear Film when warm.